Protected MasterColor[®] Metal Halide 70 Watt ED-17P 4K (Clear) Lamp Featuring ALTO[®] Lamp Technology





Ordering Information

Ordering Code	MHC70/U/MP/4K/ALTO	
ANSI Designation	M143/M98/O	
Product Number	360578	
Description	MasterColor Metal Halide	
Package Quantity	12	

Physical Characteristics

ED-17P
Clear
Medium-Screw
5 7/16" (138mm)
3 7/16" (87mm)
0.354" (9mm)
Poly Crystalline Alumina
400°C (752°F)
190°C (374°F)
3°
3°

Operating Characteristics (Photometric)

5800
4060
20,000
4000K
x380, y375
92
83

Operating Position

Universal-Open or Enclosed Luminaires

Note: Electronic ballasts are preferred for optimum performance, energy efficiency and circuit loading.

Let's make things better.

PHILIPS (+)

PHILIPS

Protected MasterColor® Metal Halide 70 Watt ED-17P 4K (Clear) Lamp Featuring ALTO® Lamp Technology

Electrical Data (Subject to change without notice)

Lamp Watts (Nominal)	. 70
Lamp Operating Voltage (rms) (Nominal) ⁽²⁾	. 100
Initial Lamp Voltage Range (rms) ⁽³⁾	
Lamp Operating Current (Amps) (rms) (Nominal)	
Lamp Current Crest Factor (Maximum)	. 1.8
Ballast Type	. ANSI M143/M98
Warm-up Time to 80% of Output	. 2 Minutes
Re-strike Time for Hot Lamp	. 4–8 Minutes
Ballast Open Circuit Voltage (Minimum)	. 235 RMS Min.
Pulse Peak Volts	. 3000 Min., 4000 Max.
Pulse Width @ 90% Peak	. 2 Micro Second Minimum
Pulse Repetition Rate (Minimum)	. 2 per Half Cycle
Minimum Operating Temperature	30°C

^(I) Measured at 100 hours of life in vertical position.

⁽²⁾ Measured at rated lamp watts on a linear reactor. LPW does not include ballast losses

⁽³⁾ Measured with the lamp operating at rated watts.

Warnings, Cautions and Operating Instructions

"WARNING: These lamps can cause serious skin burn and eye inflammation from short wave ultraviolet radiation if outer envelope of the lamp is broken or punctured. Do not use where people will remain for more than a few minutes unless adequate shielding or other safety precautions are used. Certain lamps that will automatically extinguish when the outer envelope is broken or punctured are commercially available." This lamp complies with FDA radiation performance standard 21 CFR subchapter J. (USA:21CFR 1040.30 Canada:SOR/DORS/80-381)

If the outer bulb is broken or punctured, turn off at once and replace the lamp to avoid possible injury from hazardous short wave ultraviolet radiation. Do not scratch the outer bulb or subject it to pressure as this could cause the outer bulb to crack or shatter. A partial vacuum in the outer bulb may cause glass to fly if the envelope is struck.

WARNING: The arc-tube of metal halide lamps are designed to operate under high pressure and at temperatures up to 1000°C and can unexpectedly rupture due to internal or external factors such as a ballast failure or misapplication. If the arc-tube ruptures for any reason, the outer bulb may break and pieces of extremely hot glass might be discharged into the surrounding environment. If such a rupture were to happen, THERE IS A RISK OF PERSONAL INJURY, PROPERTY DAMAGE, BURNS AND FIRE.

These lamps are designed to retain all the glass particles should an arc tube rupture occur. The following operating instructions are recommended to minimize these occurrences.

RELAMP FIXTURES AT OR BEFORE THE END OF RATED LIFE. Allowing lamps to operate until they fail is not advised and may increase the possibility of inner arc tube rupture.

This lamp contains an arc tube with a filling gas containing Kr-85 and is distributed by Philips Lighting Company, a division of Philips Electronics North America Corporation, Somerset, New Jersey 08875-6800.

CAUTION: TO REDUCE THE RISK OF PERSONAL INJURY, PROPERTY DAM-AGE, BURNS AND FIRE RESULTING FROM AN ARC-TUBE RUPTURE THE FOLLOWING LAMP OPERATING INSTRUCTIONS MUST BE FOLLOWED.

Lamp Operating Instructions:

- RELAMP FIXTURES AT OR BEFORE THE END OF RATED LIFE. Allowing lamps to operate until they fail is not advised and may increase the possibility of inner arc tube rupture.
- 2) Before lamp installation/replacement, shut power off and allow lamp and fixture to cool to avoid electrical shock and potential burn hazards.
- 3) Use only auxiliary equipment meeting Philips and/or ANSI standards. Use within voltage limits recommended by ballast manufacturer.
 - A. Operate lamp only within specified limits of operation.
 - B. For total supply load refer to ballast manufacturers electrical data.
- Periodically inspect the outer envelope. Replace any lamps that show scratches, cracks or damage.
- 5) If a lamp bulb support is used, be sure to insulate the support electrically to avoid possible decomposition of the bulb glass.
- Protect lamp base, socket and wiring against moisture, corrosive atmospheres and excessive heat.
- 7)Time should be allowed for lamps to stabilize in color when turned on for the first time. This may require several hours of operation, with more than one start. Lamp color is also subject to change under conditions of excess vibration or shock, and color appearance may vary between individual lamps.
- 8) Lamps may require 10 to 20 minutes to re-light if there is a power interruption.
- 9) Take care in handling and disposing of lamps. If an arc tube is broken, avoid skin contact with any of the contents or fragments.



PHILIPS